

PWJDM Ruckus/Zoomer Gas Cap Cover

Installation Guide

This install will take ~1 hour depending on how familiar you are with tools.

Read these instructions before you begin to make sure you have the proper tools to get the job done.

1. Remove the gascap from the bike and cover up the opening to prevent gas exposure.
2. Cutting the gascap tabs.
 - a. Use a saw, grinder, files, Dremel, or whatever you need to grind the tabs off the gascap.
 - b. We want to grind off enough of the tab for the cover to rest on the flat area around the keyhole.
 - c. You can check for clearance by pressing a flat edge to your gascap.



3. Fitting the cover.
 - a. Put the gascap back onto the gastank.
 - b. Press on the PWJDM cover and twist it so the keyholes line up.
 - c. Tighten the setscrews just enough to feel resistance and keep thieves from getting your bling.
4. Ride baby ride!